17 Dynamics Calculations Using the Time and Frequency Domains

- 1. Don't turn anything in on this part. The FFT (Fast Fourier Transform) is a standard method for decomposition of a signal into its harmonic components. You need to know a few specific items about it:
 - (a) The length of the input signal x in the time domain is N. The FFT itself doesn't care about what is the time step between x_n and x_{n+1} , although the spacing must be uniform; below, we'll call it Δt . Hence x_1 occurs at time 0, x_2 is at time Δt , and so on, up to x_N taken at time $(N-1)\Delta t$.
 - (b) The formal definition of the transform and its inverse in MATLAB is

$$X_{k} = \sum_{n=1}^{N} x_{n} e^{-i2\pi(k-1)(n-1)/N}, 1 \le k \le N;$$

$$x_{n} = \frac{1}{N} \sum_{k=1}^{N} X_{k} e^{i2\pi(k-1)(n-1)/N}, 1 \le n \le N,$$

where $i = \sqrt{-1}$. So the FFT takes a uniformly-spaced time signal x and makes a uniformly-spaced frequency signal X, of the same length. It is like a Fourier integral because of the exponential: $e^{iz} = \cos z + i \sin z$. Furthermore, you notice that the FFT (the transform that makes X) is a summation between the timedomain signal x and an exponential with imaginary argument, which has unity magnitude. Thus, the size of the elements in X are roughly the size of x, multiplied by N. The inverse FFT has the factor 1/N out front so as to cancel this effect out; ifft(fft(x)) = x;. Because of this arrangement, however, you can't take the FFT of two signals, multiply them (to effect a convolution), take the inverse FFT, and expect to get the right scaling - each FFT induces a scaling of N, but the IFFT only corrects for one of them. Remembering this point will save you a lot of trouble in using the FFT in MATLAB!

You can see this scaling for example with

x = sin(0:0.1:100); X=fft(x); plot(abs(X));. Here, you plot the absolute value (abs()) which is synonymous with magnitude, because X is complex.

There is another scaling factor to notice, but this is easier; because the Fourier integral involves both negative and positive frequencies, it puts half the area on each side.

(c) What are the uniformly-spaced frequencies that go with X? For the case of odd N (typical if the final time T is an even multiple of Δt), we have:

$$\omega_k = \begin{bmatrix} 0 & 1 & \cdots & \frac{N-1}{2} & \frac{1-N}{2} & \cdots & -1 \end{bmatrix} \frac{2}{N-1} \frac{\pi}{\Delta t}$$

If you count these, you will see that there are N of them, exactly one frequency to go with each element of X. More interesting are the values, which start from

zero and go to the Nyquist rate $\pi/\Delta t$, and then jump back to the negative of the Nyquist rate, and go to almost zero. Together, these cover completely the range of negative Nyquist rate to positive Nyquist rate. The FFT can't see beyond the Nyquist rate, so we see that, in general, increasing N but keeping ΔT constant will give more resolution to a Fourier decomposition.

You can try making up the frequency vector that goes with the example above: Do the indices of the peak value in X correspond with plus and minus one radian per second?

2. Now we use the FFT as a tool for analyzing system response to both specific and, later, to stochastic forcing signals.

First, find the impulse response of the system x'' + 0.1x' + x = u, using your simulation based on ode45. You'll have to construct the impulse explicitly in the derivative call, with something like this:

if t < epsilon, u0 = 1/epsilon ; else, u0 = 0 ; end;

You can try values of $\epsilon < 0.1$ or so for this system. The response we are looking for is x, not x', so you'll have to pick one column only out of the vector that ode45 returns; call it h. Use an initial time of zero in the simulation, and final time T = 100 seconds.

- 3. Regularize the impulse response you calculated by first making a uniformly spaced time vector like this: treg = 0:dt:T; a value for dt of 0.1 or so is OK. This treg is contrasted with the time vector returned by ode45, which is *not* uniformly spaced, because MATLAB is automatically adjusting the time step as it does the integration for you. Use the spline function to make h line up with the uniform time vector treg: [hreg] = spline(t,h,treg) ;.
- 4. Now, make up a new input u, that we will use in the rest of this problem: u = 1 if t < T/2, u = 0 if $t \ge T/2$. You need to put this in as an input in the derivative function for the simulation, and you need to also create it as a vector **ureg** that lines up with **treg**.
- 5. Now we are ready to make the computation of the system response to the input u in three different ways! The **first** is the simplest just run the simulation with the input u. Make a plot of x vs. t.
- 6. The **second** method is to convolve the input *u* with the impulse response *h*. We have to use a consistent time base, and that is why we made **ureg** and **hreg**. MATLAB has a command called **conv** which you can use; the convolution integral is the same as this vector convolution if you multiply the latter by dt; i.e., we have to calculate the *area* under the curve.

Plot the first N elements of the convolution result versus treg. It should look almost the same as what you found from the direct simulation.

7. The **third** method is to multiply the FFT of the impulse response with the FFT of the input u. In this case, you will do a vector pointwise multiplication (.* is the syntax)

of U = fft(ureg) and the FFT of h. You could execute fft(hreg) of course, which builds off your original simulation. But the crucial observation here is that we already know the transform of the impulse response - it is the same as the transfer function!

$$H = \frac{1}{-\omega^2 + 0.1\sqrt{-1}\omega + 1}.$$

This is the calculation you will make, and you have to use the oddly-ordered frequency vector that is defined in (a) in order to make it work properly.

In summary for this step then, point-wise multiply the vector U times the vector H, then take the inverse FFT to get a third calculation for the response x when the system is driven by u. The IFFT result plotted versus **treg** should come out to be very close to the two results computed before. (Note you will get a little complaint from the plotting command, which doesn't know what to do with the very small imaginary parts of the IFFT result - ignore it.)

8. Why didn't we have to worry about the N-scaling of the FFT when we did the IFFT?

The overlay plot for the three methods is given in the plot below; code is attached. In the last question, we don't have to worry about the N-scaling in the IFFT because $H(j\omega)$ is not computed with the FFT and so doesn't have the factor of N. Thus the IFFT "undoes" the N-scaling introduced by the FFT of U, in the same way that ifft(fft(x)) = x.



Figure 3: Overlay of system response by three different methods.

```
<u>%_____</u>
% Show the equivalence of time-domain simulation, convolution, and
% frequency-analysis of an LTI system.
% Franz Hover MIT Mechanical Engineering
clear all; close all;
global m b k epsilon T ;
m = 1;
              % mass of oscillator
             % damping
b = .1;
         % stiffness
k = 1;
epsilon = .1 ; % time duration used for delta function
dt = .1;
               % uniform time step
T = 100;
           % final time; make this an even multiple of dt !!!
           % Also, if T is big, we can minimize finite length effects
treg = 0:dt:T;
                 % regular time vector
N = length(treg);
ureg = [ones(1, (N+1)/2), zeros(1, (N-1)/2)];
   % regular input vector (half ones, half zeros)
wreg = [0:(N-1)/2, (1-N)/2:-1] / (N-1) * 2*pi/dt;
   % regular frequency vector
% first, get the time domain impulse response
[th,h] = ode45('tripleMethod_dxdt1',[0 T],[0 0]);
h = h(:,2) ; % pick out just the second column - it goes with state x
[hreg] = spline(th,h,treg) ; % regularize h to align with treg
% 1. make the response to u using the simulation directly
[t1,y1] = ode45('tripleMethod_dxdt2',[0 T],[0 0]);
y1 = y1(:,2);
% 2. make the response using convolution in time domain
y^2 = conv(ureg, hreg) * dt;
\% 3. make the response using the FFT - convolution in freq. domain
U = fft(ureg);
H = ones(size(wreg))./(-m*wreg.^2 + sqrt(-1)*wreg*b + k);
Y = U.*H;
y3 = ifft(Y);
```

```
% ... and compare!
figure(1);clf;hold off;
subplot('Position',[.2 .2 .6 .4]);
plot(t1,y1,treg,y2(1:N),'--',treg,(y3),':') ;
legend('simulation','convolution in time domain','convolution in freq. domain');
xlabel('seconds');
ylabel('y');
print -depsc tripleMethod.eps
%_-----
function [ydot] = tripleMethod_dxdt1(t,y);
global m b k epsilon ;
if t < epsilon,
  u = 1/epsilon ;
else,
  u = 0;
end;
ydot(1,1) = -b/m*y(1) - k/m*y(2) + u;
ydot(2,1) = y(1);
%_____
function [ydot] = d2_1_dxdt2(t,y);
global m b k T ;
if t < T/2,
  u = 1;
else,
  u = 0;
end;
ydot(1,1) = -b/m*y(1) - k/m*y(2) + u;
ydot(2,1) = y(1);
```

2.017J Design of Electromechanical Robotic Systems Fall 2009

For information about citing these materials or our Terms of Use, visit: http://ocw.mit.edu/terms.